

Tuckerman Piezo Ignitor Service Tips



When there is no spark from the Piezo Ignitor, try cleaning the tip with a very fine sand paper. If it still does not spark try cutting the very tip off the Piezo with a sharp pair of pliers. If neither of these actions work then the Piezo might need replacing.

If your BBQ turns itself off as soon as you let go the Control Knob then that would indicate that the Control Knob is faulty or damaged in some way. To test this, pull the Control Knob straight off and try starting your BBQ with a pair of pliers. If the flame does not go out then your Control Knob needs replacing.

Replacement parts can be ordered on our website www.sovereignbbqs.com .